RadioShack®

49-1002

Wireless Security Keychain Remote

Use your wireless keychain remote to arm and disarm your Wireless Security Kit (49-1000). Your Wireless Security Kit includes one keychain remote, and you can purchase up to 15 additional keychain remotes (16 total) to use with your system. Your keychain can also control devices connected to remote modules (such as a lamp) that are controlled by your Wireless Security System. Your keychain includes random digital security coding for enhanced security.

Press to arm your security system (door/window sensors, motion detectors).

Press to disarm your security system.

on and **off** (**A** and **B**) allow you to turn on and off up to two devices that are connected to home automation modules, such as a 61-3002 Lamp Module. Use this feature to turn lights on and off while you are away from home.

Thank you for purchasing your Wireless Security Keychain Remote from RadioShack.

what's included

keychain remote
Two CR2016 lithium batteries (installed)

registering your keychain remote

1. Press and hold down **arm** for 3-4 seconds, and then release it.

Note: If you need to register the keychain remote a second time, remove the batteries, and then hold down **arm** for 3-4 seconds to pick up a random code.

2. Press **menu start** ↑ or ↓ on your security system console. ***ENTER PIN*** (Personal Identification Number) appears on the display.
3. Use the console keypad to enter your four-digit PIN. * appears on the display as each digit is pressed. After you enter your PIN, ***1. INSTALL*** appears.
4. Press **ok** and ***1. INSTALL*** / ***ZONE*** appears.
5. Press any button on your keychain remote. ***RMOT 1 SET*** appears on the console display to confirm registration.
6. Press **clear** to return to the setup screen. Press **clear** again to confirm your exit from setup mode. Press **1** to return to the main display, or press **2** to stay in setup mode.

See your Wireless Security Kit User Guide (49-1000) for instructions on changing your PIN.

Please read this user's guide before installing, setting up and using your new product
www.radioshack.com

arming/disarming your system

arming the system

Press **arm** on your keychain remote. All door/window sensors and motion detectors that are part of your security system are armed instantly.

disarming the system

When you return home, you have 30 seconds to enter and disarm the system from the console (using your PIN) before the alarm sounds. Thirty seconds is the default entry time. Refer to your Wireless Security Kit User Guide for details on how to change the default delay and entry times. Press **disarm** on the keychain remote to instantly disarm the system.

- Dispose of old batteries promptly and properly.
- Do not burn or bury batteries.
- Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

Warning: Keep away from small children. If swallowed, promptly see doctor.

replacing the batteries

Your keychain remote comes with two CR2016 button-cell batteries installed. If your keychain stops working properly, replace the batteries.

1. Gently pry the two halves of the keychain remote apart as shown.

2. Remove the old batteries and replace them with two fresh CR2016 button-cell batteries. Fresh batteries must be inserted within 30 seconds in order to retain the security code.
3. Press the two halves of the remote back together.
4. Press **arm** to arm your system. If the system does not arm, you must register the keychain remote again. To register the remote, follow steps 1-6 in "registering your keychain remote" on page 1.

FCC information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the *FCC Rules*. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult your local RadioShack store or an experienced radio/TV technician for help.
- If you cannot eliminate the interference, the FCC requires that you stop using your keychain remote.

Changes or modifications not expressly approved by RadioShack may cause interference and void the user's authority to operate the equipment.

This device complies with Part 15 of the *FCC Rules*. Operation is subject to the condition that this device does not cause harmful interference.

©2004. RadioShack Corporation.
All rights reserved. RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

49-1002
07A04
Printed in China

RadioShack